FISHMAN FLUENCE™

Classic Open Core Humbucker Set
Custom Setup - 2 (hum cancelling in all positions)
5-Way Super Switch

Neck: Classic Neck
Open Core

Bridge: Classic Bridge
Open Core

9V Battery

(+)

(-)

Remove Solder Bridge
To Access The Solder Pads Underneath

Bridge Ground

Ring

Sleeve

Output Jack

Tip

25k

Volume
Pull for
Voice-2

25k

22uF

Tone
Down Position (Voice 3 Inner Coils)
Up Position (Voice 3 Outer Coils)

Neck Pickup

Bridge Pickup

Pickup Selector
5-Position
4P5T "Super Switch"

Pickup Selector Function
1. Bridge Humbucker (Voice-1 or 2 Selectable)
2. Bridge & Neck (Single Coil Voice-3, Inner/Outer Coils Selected with Push/Pull)
3. Bridge & Neck Humbuckers (Voice-1 or 2 Selectable)
4. Bridge & Neck (Single Coil Voice-3, Inner/Outer Coils Selected with Push/Pull)
5. Neck Humbucker (Voice-1 or 2 Selectable)